

### VFR-015

| Fils Bornes | Paramètres |
|-------------|------------|
| 1 GND       | F0.11 = 1  |
| 2 DI1       | F1.00 = 1  |
| 4 DI2       | F1.01 = 3  |
| 6 DI3       | F1.02 = 2  |
|             | F1.10 = 2  |

RAZ usine: Y0.00 = 3

### VFR-050 /-91

| Fils Bornes | Paramètres |
|-------------|------------|
| 1 COM       | F0.11 = 1  |
| 2 DI1       | F1.00 = 1  |
| 4 DI2       | F1.01 = 3  |
| 6 DI3       | F1.02 = 2  |
|             | F1.10 = 2  |

RAZ usine: Y0.00 = 3

